

Parts needed (costs under \$3!):

#2 Holed Stopper

5 Ft. 1/4" ID Tubing

3 In. 3/8" ID Tubing

## Poor Man's Counter Pressure Filler

- ✓ Got \$3.00
- ✓ #2 Holed Stopper
- ✓ 5 Ft. 1/4" ID Tubing
- ✓ 3 In. 3/8" ID Tubing



# Poor Man's Counter Pressure Filler

- ✓ Process:
- ✓ Sanitize
- ✓ Set Keg at 4-6 PSI
- ✓ Attach to Faucet



# Poor Man's Counter Pressure Filler

- ✓ Attach to Bottle
- ✓ Gentle Squeeze of Stopper w/Thumb
- ✓ Allow Slight Overflow of Foam

